Safety Precautions

You should take the following safety precautions when using your air conditioner.

⚠ *WARNING*

- If you don't follow the safety precautions, you may get the risk of an electric shock, injury or death.
- The manufacturer or qualified service personnel must install this air conditioner.
- Unplug the electric power before repairing, installing or cleaning.

DURING OPERATION

- Do not repair the air conditioner at your discretion. It is recommended to contact a service center directly.
- Never spill any kind of liquid on the air conditioner. If this happens, unplug or turn off the air conditioner and contact an authorized service center.
- Do not insert anything between the airflow blades to prevent damage of the inner fan and consequent injury. Keep children away from the air conditioner.
- Do not place any obstacles in front of the air conditioner.
- Do not spray any kind of liquid into the indoor unit. If this happens, turn off the breaker and contact a service center.
- Make sure that the air conditioner is well ventilated at all times: Do not place a cloth or other materials over it.
- Remove the batteries if you don't use the remote control for a long time. (If applicable)
- Use the remote control within 23ft(7m) from the indoor unit. (If applicable)

DISPOSING OF THE UNIT

- Before throwing out the air conditioner, remove the batteries from the remote control.
- When you dispose of the air conditioner, consult your dealer. If pipes are removed incorrectly, refrigerant may blow out and cause air pollution. When it contacts with your skin, it can cause skin injury.
- The package of the air conditioner should be recycled or disposed properly for environmental reasons.

OTHERS

- Never store or load the air conditioner upside down or sideways to prevent the damage of the compressor.
- Young children or infirm persons should be always supervised when they use the air conditioner.
- Max current is measured according to IEC standard for safety.
- Current is measured according to ISO standard for energy efficiency.

Contents

◆ ***PREPARATION***
- ■ Safety Precautions 2
- ■ Name of Each Part 4
- ■ Remote Control - Buttons and Display 6
- ■ Inserting the Remote Control Batteries 7
- ■ Getting Started 8

◆ ***OPERATION***
- ■ Selecting the Auto Mode 9
- ■ Selecting the Cool Mode 10
- ■ Selecting the Heat Mode 11
- ■ Selecting the Dry Mode 12
- ■ Selecting the Fan Mode 13
- ■ Selecting Good Sleep Mode 14
- ■ Selecting the Turbo Function 16
- ■ Selecting the Energy Saving Function 17
- ■ Adjusting the Airflow Direction Vertically 18
- ■ Adjusting the Airflow Direction Horizontally 19
- ■ Setting the On Timer 20
- ■ Setting the Off Timer 21
- ■ Setting the Sleep Timer 22
- ■ Setting the 1 Hour Timer 23

◆ ***RECOMMENDATIONS FOR USE***
- ■ Operating Recommendations 24
- ■ Temperature and Humidity Ranges 25
- ■ Operating Your Air Conditioner Without the Remote Control 25
- ■ Troubleshooting Guide 26
- ■ Cleaning Your Air Conditioner 27
- ■ Cleaning Deodorizing and Bio Filter (Option) 28
- ■ Periodical Checks 29
- ■ Protections enabled by the Unit control system 30

Name of Each Part

The design and shape can be changed according to the model.

Indoor Unit



Outdoor Unit

AQV36J✳✳



Remote Control - Buttons and Display



Note

- Each mode indicator shows the current setting and the battery life.
- You can check the battery life by pressing the Battery button.
- The number of the battery life indicator means the remaining battery life. Replace the batteries when only one battery life indicator remains.

Inserting the Remote Control Batteries

You must insert or replace the remote control batteries when:

- ***You purchase the air conditioner***
- ***The remote control does not work correctly***

Note

- Use two AAA, LR03 1.5V batteries
- Do not use old batteries or different kinds of batteries together.
- Batteries may be completely discharged after 12 months, even if they have not actually been used.

1 Remove the battery cover in the rear of the remote control by pushing it with your thumb.



2 Insert two batteries, respecting the polarities as indicated by the + and - symbols.



3 Close the cover by sliding it back in its place.

Getting Start

The User's Manual provides you with valuable information about your air conditioner. Please read this manual carefully before using the air conditioner. It will help you take full advantage of the unit's features.

You have already seen the basic description of the unit on pages from 4 to 6. Starting up with the next page, you will find a series of step-by-step procedures for each function available.

The illustrations in the step-by-step procedures use three different symbols:

PRESS	**PUSH**	**HOLD DOWN**

Selecting the Auto Mode

You can select the Auto mode if you want to cool or heat your room automatically. You can adjust the temperature in this mode.

1 If necessary, press the POWER (On/Off) button.

Result:
- ◆ The operation indicator on the indoor unit lights up.
- ◆ The air conditioner starts up in the mode you selected last.
- ◆ The indoor unit beeps.

2 Press the MODE button on the remote control until Auto is displayed.

Result:
- ◆ The indoor unit beeps each time you press the MODE button.
- ◆ The air conditioner runs in the Auto mode.
- ◆ The Auto mode cools or heats the room depending on the set temperature.
- ◆ The air conditioner changes the Cool or Heat mode automatically depending on the current temperature during operation.

Note You can change modes at any time.

3 Press the ▽ | △ button to adjust the temperature until the required temperature is displayed.
You can set the temperature between 61°F(16°C) and 86°F(30°C).

Result:
- ◆ Each time you press the ▽ | △ button:
  - The temperature is adjusted by 1°F
  - The indoor unit beeps



Selecting the Cool Mode





You can select the Cool mode if you want to cool your room.
You can adjust the temperature and the fan speed when cooling

1 If necessary, press the POWER (On/Off) button.

Result:
- ◆ The operation indicator on the indoor unit lights up.
- ◆ The air conditioner starts up in the mode you selected last.
- ◆ The indoor unit beeps.

2 Press the MODE button on the remote control until ❄ is displayed.

Result:
- ◆ The indoor unit beeps each time you press the MODE button.
- ◆ The air conditioner runs in the Cool mode.

Note You can change modes at any time.

3 Press the ▽ | △ button to adjust the temperature until the required temperature is displayed.
You can set the temperature between 61°F(16°C) and 86°F(30°C).

Result:
- ◆ Each time you press the ▽ | △ button:
  - The temperature is adjusted by 1°F
  - The indoor unit beeps
- ◆ If the room temperature is higher than the selected temperature, the air conditioner starts cooling.
- ◆ If the room temperature reaches the set temperature, the air conditioner stops cooling, but the fan operates consistently.

4 Press the FAN SPEED button to select the fan speed until the required settingis displayed.

- Automatic (rotated : → →)
- Low
- Medium
- High
- Maximum

Result:
- ◆ Each time you press the FAN SPEED button, the indoor unit beeps.
- ◆ The fan speed indicator increases and decreases continuously and turns round each time you press the FAN SPEED button.

5 To control the airflow direction, refer to pages 16 and 17.

Selecting the Heat Mode

You can select the Heat mode if you want to heat your room.
You can adjust the temperature and the fan speed when heating.

1 If necessary, press the POWER (On/Off) button.

Result:
- ◆ The operation indicator on the indoor unit lights up.
- ◆ The air conditioner starts up in the mode you selected last.
- ◆ The indoor unit beeps.

2 Press the MODE button on the remote control until ☼◂ is displayed.

Result:
- ◆ The indoor unit beeps each time you press the MODE button.
- ◆ The air conditioner runs in the Heat mode.

Note You can change modes at any time.



3 Press the ▽ | △ button to adjust the temperature until the required temperature is displayed.
You can set the temperature between 61°F(16°C) and 86°F(30°C).

Result:
- ◆ Each time you press the ▽ | △ button:
  - The temperature is adjusted by 1°F
  - The indoor unit beeps
- ◆ If the room temperature reaches 9°F higher than the set temperature, the air conditioner stops heating, but the fan operates consistently.
- ◆ If the room temperature reaches 5°F lower than the set temperature, the air conditioner starts heating again.

4 Press the FAN SPEED button to select the fan speed until the required settingis displayed.

- Automatic (rotated : → →)
- Low
- Medium
- High
- Maximum

Result:
- ◆ Each time you press the FAN SPEED button, the indoor unit beeps.
- ◆ For the first 3~5 minutes, the fan may not operate to prevent the cool air from running out of the indoor unit. It helps to warm the air in your room sufficiently.

5 To control the airflow direction, refer to pages 16 and 17.

Selecting the Dry Mode

You can select the Dry mode if you want to dehumidify your room. You can adjust the temperature in this mode.

1 If necessary, press the POWER (On/Off) button.

Result:
- The operation indicator on the indoor unit lights up.
- The air conditioner starts up in the mode you selected last.
- The indoor unit beeps.



2 Press the MODE button on the remote control until ◀ is displayed.

Result:
- The indoor unit beeps each time you press the MODE button.
- The air conditioner runs in the Dry mode.

Note You can change modes at any time.



3 Press the ▽ | △ button to adjust the temperature until the required temperature is displayed.
You can set the temperature between 61°F(16°C) and 86°F(30°C).

Result:
- Each time you press the ▽ | △ button:
  - The temperature is adjusted by 1°F
  - The indoor unit beeps
- The air conditioner starts dehumidifying and the fan speed is adjusted automatically.

4 To control the airflow direction, refer to pages 16 and 17.

Selecting the Fan Mode

You can select the Fan mode if you want to ventilate your room. It helps to refresh the air in your room. You can adjust the fan speed in this mode.

1 If necessary, press the POWER (On/Off) button.

Result:
- ◆ The operation indicator on the indoor unit lights up.
- ◆ The air conditioner starts up in the mode you selected last.
- ◆ The indoor unit beeps.

2 Press the MODE button on the remote control until ◀ is displayed.

Result:
- ◆ The indoor unit beeps each time you press the MODE button.
- ◆ The air conditioner runs in the Fan mode.
- ◆ The temperature is set automatically.

Note You can change modes at any time.



3 Press the FAN SPEED button to select the fan speed until the required setting is displayed.

- Low
- Medium
- High

Result: Each time you press the FAN SPEED button, the indoor unit beeps.

4 To control the airflow direction, refer to pages 16 and 17.

Selecting Good Sleep Mode

Good Sleep mode helps users to fall asleep well after going to bed whether being too hot to sleep or being awakened by coldness. The Good Sleep mode can be selected only when the air conditioner is switched on in cool/heat mode.



1 If necessary, press the Power button.

Result:
- The operation indicator on the indoor unit lights up.
- The air conditioner starts up in the mode you selected last.
- The indoor unit beeps.



2 Press the Mode button to select ❄ ◀ or ☼ ◀ mode.

Result:
- The indoor unit beeps each time you press the Mode button.
- The air conditioner runs in cool or heat mode.

3 Press the good'sleep button until the indicator appears on the remote control.

- In the case of adjusting time
  - Press the good'sleep button to adjust desired operation time from 1 to 12 hours. Good Sleep mode will automatically stop after the set time.
  - Press the Set/Cancel button.

Result: In the case of adjusting the extra time for Good Sleep mode,you should press the Set/Cancel button within 10 seconds.If you do not press the Set/Cancel button within 10 seconds.Good Sleep mode will automatically stop in 8-hour operation.



4 Press the ▽ | △ button to adjust the temperature until the required temperature is displayed.
You can set the temperature between 61°F(16°C) and 86°F(30°C).

Result:
- Each time you press the ▽ | △ button:
  - The temperature is adjusted by 1°F
  - The indoor unit beeps

Temperature changes in good' sleep mode

To prevent excessive cooling/heating during sleep, the good' sleep mode automatically modifies the temperature setting in accordance with the time setting. Temperature and air current change according to the three stages; Falling asleep, Sound sleep, and Waking up from good' sleep mode, and then the air conditioner will automatically turn off when the set time has elapsed.

Three stage good' sleep prevents you from having difficulty sleeping on extremely hot/cold nights.

① **Falling asleep** : Eases you into sleep by dropping the temperature.
② **Sound sleep** : Relaxes your body and raises your temperature slightly.
③ **Waking up from** good' sleep **mode** :
Allows you to wake up to comfortable crisp air making you feel refreshed and energized.

- Set the Off timer in good' sleep mode for more than 5 hours. Sleep may be disturbed if the good' sleep mode is set for too short or too long a time because the temperature changes are set to an 8-hour cycle.
- If the good' sleep mode is set for less than 4 hours, the operation will stop at the set time. If the good' sleep mode is set for over 5 hours, the last hour will run in Waking Up stage before shutting off.
- Recommended set temperature is between 77˚F~81˚F for cooling and 69.8˚F~73.4˚F for heating.

Cool mode



Heat mode



Selecting the Turbo Function



You can select the Turbo Function if you want to cool or heat your room in the fastest way. After the 30-minute operation with the maximum setting, it returns to the previous setting.

1 If necessary, press the POWER (On/Off) button.

Result:
- ◆ The operation indicator on the indoor unit lights up.
- ◆ The air conditioner starts up in the mode you selected last.
- ◆ The indoor unit beeps.

2 Press the TURBO button.

Result:
- ◆ The temperature and fan settings are adjusted automatically.
- ◆ The air conditioner cools or heats the room as quickly as possible.
- ◆ After 30 minutes, the air conditioner is reset automatically to the previous setting.
- ◆ You can select the Turbo function in the Auto, Cool and Heat mode. If you select this function in the Dry or Fan mode, the mode changes to the Auto mode.

3 Press the TURBO button again to stop the Turbo Function before the end of the 30-minute period.

Result: The air conditioner is reset automatically to the previous setting.

4 To control the airflow direction, refer to pages 16 and 17.

Selecting the Energy Saving Function

You can select the Energy Saving Function to save energy when cooling or heating.

1 If necessary, press the POWER (On/Off) button.

Result:
- ◆ The operation indicator on the indoor unit lights up.
- ◆ The air conditioner starts up in the mode you selected last.
- ◆ The indoor unit beeps.

2 Press the ENERGY SAVING button.

Result:
- ◆ The indoor unit beeps.
- ◆ The air conditioner runs in the Energy saving mode.
- ◆ The outer airflow blade moves up and down.
- ◆ To stop the Energy saving mode, press the ENERGY SAVING again.

Note You can select the Energy saving mode only in the Cool and Heat mode.

3 Press the ▽ | △ button to adjust the temperature until the required temperature is displayed.

4 Press the FAN SPEED button to select the fan speed until the required setting is displayed.

5 To control the airflow direction, refer to pages 16 and 17.

Adjusting the Airflow Direction Vertically

You can adjust the airflow direction vertically. The outer airflow blade moves up and down to increase the efficiency of the cooling or heating operation.

1 Press the FLAP button until the required direction is set.
Result: The outer blade is adjusted vertically.

2 Press the FLAP button to move the blade up and down automatically during operation.

3 Press the FLAP button again to stop the blade moving up and down.

Note

If you turn the air conditioner...	*Then the blade...*
Off	is closed completely.
On	set to the default position.

Adjusting the Airflow Direction Horizontally

You can adjust the airflow direction horizontally with your hands.
The inner blades with small fins moves the air to the required direction.

1 Adjust the inner blades by moving them to left or right.



Setting the On Timer

You can set the On Timer to turn on the air conditioner automatically at the appointed time. You can set the time from 1 hour to 24 hours.

1 Press the ON button until the required time is displayed to set the On Timer. You can set the time between 1 hour and 24 hours.

2 Press the SET/CANCEL button to complete the setting.

Result:
- ◆ The remaining time is displayed.
- ◆ The timer indicator stops blinking.
- ◆ The selected mode and the temperature on the display disappear after 10 seconds.
- ◆ The air conditioner turns on automatically at the appointed time and the On Timer setting disappears.



3 Press the MODE button until the desired mode is displayed at the top of theremote control to select the mode in advance.

Result:
- ◆ The air conditioner operates in the selected mode when it is turned on.

Note If you don't use the remote control after setting the On Timer, it turns off automatically after 25 hours.

To Cancel the On Timer



1 Press the SET/CANCEL button to cancel the On Timer.

Note If you press the SET/CANCEL button, both the On Timer and the Off Timer are canceled.

Setting the Off Timer

You can set the Off Timer to turn off the air conditioner automatically at the appointed time. You can set the time from 1 hour to 24 hours.

1 Press the OFF button until the required time is displayed to set the Off Timer. You can set the time between 1 hour and 24 hours.



2 Press the SET/CANCEL button to complete the setting.

Result:
- The remaining time is displayed.
- The timer indicator stops blinking.
- The air conditioner turns off automatically at the appointed time and the Off Timer setting disappears.



Example **If you would like to turn the air conditioner on after 2 hours and to operate it for 2 hours:**

1. Press the ON button until '2.0 Hr' is displayed.
2. Press the SET/CANCEL button.
3. Press the OFF button until '4.0 Hr' is displayed.
4. Press the SET/CANCEL button.

Note You can check or change the mode and/or the temperature by pressing the MODE button or the ▽ | △ button after setting the Off Timer.

To Cancel the Off Timer

1 Press the SET/CANCEL button to cancel the Off Timer.



Note If you press the SET/CANCEL button, both the On Timer and the Off Timer are canceled.

Setting the Sleep Timer

You can set the Sleep Timer to turn off the air conditioner automatically while you are sleeping. The air conditioner stops operating 6 hours after you set the Sleep Timer.

1 Press the SLEEP button until the indicator appears on the remote control.

Result:
- The indoor unit beeps.
- The air conditioner will be controlled as indicated in the illustrations below.

Note You can set Sleep Timer only in the Cool or Heat mode.

Cooling

The set temperature is increased by 1°C every hour. After the increase of 2°C, the temperature is maintained for 4 hours.



Heating

The set temperature is decreased by 1°C every hour. After the decrease of 2°C, the temperature is maintained for 4 hours.



To Cancel the Sleep Timer

1 Press the SLEEP button to cancel the Sleep Timer.

Result:
- The indoor unit beeps.
- The indicator is no longer displayed.
- The air conditioner operates normally.

Setting the 1 Hour Timer

You can set the 1 Hour Timer to turn off the air conditioner automatically after an hour. It is the quick and convenient way using only one button.

1 Press the 1HR. button until the 1HR. indicator appears on the remote control.

2 Press the MODE button until the desired mode is displayed at the remote control to select the mode after setting the 1 Hour Timer.

Result: The air conditioner operates in the selected mode for an hour.

Note If you set the 1 Hour Timer when the air conditioner is turned off, the air conditioner turns on and operates for an hour.

To cancel the 1 Hour Timer

1 Press the 1HR. button to cancel the 1 Hour Timer.

Result:
- The indoor unit beeps.
- The 1HR. indicator is no longer displayed.
- The air conditioner operates normally.



Operating Recommendations

When you use your air conditioner, it is recommended to read the following :

Topic	Recommendation
Heating capacity	The heat pump inside the air conditioner absorbs heat from outside air and brings it indoors. If the temperature of the outside air drops, the air conditioner heats less. If the room is not warm enough, use an additional heating appliance.
Warm air circulation	The air conditioner circulates warm air to heat your room. It will take some time to warm the air in your room entirely after the air conditioner turns on. Therefore, turn the air conditioner on in advance.
Frost	When you select the Heat mode, frost may form in the outdoor unit due to the low temperature and high humidity. If this happens : ◆ The heating operation is stopped. ◆ The air conditioner defrosts automatically for about 7 minutes. After about 7 minutes, the air conditioner starts operating again normally.
High indoor and outdoor temperatures	If both the indoor and outdoor temperatures are high when you select the Heat mode, the fan and the compressor of the outdoor unit may stop at times. This is normal; wait until the air conditioner turns on again.
Power failure	If power failure occurs when the air conditioner is operating, the air conditioner turns off. When the power returns, the air conditioner starts up again automatically.
Protection mechanism	When the air conditioner is started immediately after being plugged in or stopped, the normal operation starts up after 3 minutes for the reason of protection.

Temperature and Humidity Ranges

If you check the following tables, you can use your air conditioner more efficiently.

If the air conditioner is used at...	*Then...*
Heating capacity	The air conditioner may stop operating for the reason of protection.
Low temperatures	Water may leak and some malfunction may occur if the heat exchanger freezes.
High humidity levels	Water may condense and drip from the surface of the indoor unit if you don't use the air conditioner for a long time.

Operation	Outdoor Temperature	Indoor Temperature	Indoor Humidity
Heating	5°F to 75°F approx.	80°F or less	-
	-15°C to 24°C approx.	27°C or less	
Cooling	14°F to 109°F approx.	61°F to 90°F approx.	80% or less
	-10°C to 43°C approx.	16°C to 32°C approx.	
Dehumidifying	14°F to 109°F approx.	61°F to 90°F approx.	-
	-10°C to 43°C approx.	16°C to 32°C approx.	

✳ ***If the outdoor temperature is as low as 32°F/0°C, the heating capacity drops up to 70~80% depending on the operating condition.***
If you use the air conditioner over 90°F/32°C (indoor temperature), the cooling capacity may drop.

Operating Your Air Conditioner Without the Remote Control

You can operate your air conditioner directly without the remote control.

1 To turn the air conditioner on, press the On/Off button on the right side of the indoor unit.

Result:
- ◆ The Operation indicator on the indoor unit lights up.
- ◆ The indoor unit beeps.
- ◆ The air conditioner starts up in the appropriate mode for the room temperature. The air conditioner changes the Cool or Heat mode automatically depending on the current temperature during operation.



2 To turn the air conditioner off, press the On/Off button again.

Note Even if you turned the air conditioner on with the On/Off button, you can control it with the remote control.



Troubleshooting Guide

Before contacting the service center, check the following. It will save your time and theexpense of an unnecessary call.

Problem	Explanation/Solution
The air conditioner does not operate.	◆ Check if the circuit breaker of the air conditioner is switched on. ◆ Check if the air conditioner is turned on. If necessary, press the POWER (On/Off) button on the remote control. ◆ Check if the Timer indicator on the indoor unit is on. If so: - Wait until the set time is reached and the air conditioner starts automatically. - Cancel the Timer. (See pages 18 and 19 for further details)
The air conditioner does not operate with the remote control.	◆ Check if there are no obstacles in front of the indoor unit. ◆ Check the remote control batteries. ◆ Make sure that you are with in 7 meters from the indoor unit.
No beep is heard when you press the POWER (On/Off) button on the remote control.	◆ Check if you are pointing the remote control at the remote control sensor on the right side of the indoor unit. ◆ Replace the remote control batteries if necessary.
The air conditioner does not cool or heat.	◆ Check if the correct operating mode has been selected (Auto, Cool, Heat). ◆ The room temperature may be too low or too high. ◆ Check if the air filter is dirty; refer to page 25 for cleaning instructions. ◆ Check that there is no obstacle in front of the outdoor unit.
When heating, the required room temperature is never reached and the air conditioner frequently stops.	◆ Check if the required temperature is set correctly. ◆ Increase the fan speed. ◆ If the airflow is directed upwards, set the blade downwards with the remote control.
The fan speed does not change when you press the FAN SPEED button.	◆ Check if the mode is set to the Auto, Cool, Heat or Fan mode; in the Dry mode, the fan speed changes automatically.
The airflow direction does not change when you press the FLAP button.	◆ Check if the air conditioner has been turned on; if necessary, press the POWER (On/Off) button on the remote control.
The timer is not correctly triggered.	◆ Check if the timer is set correctly; see pages 18 and 19.
Odor permeates into the room during operation.	◆ You can use the Fan mode to ventilate your room.

Cleaning Your Air Conditioner

For the best use of your air conditioner, you must clean it every 2 weeks to remove the dust that accumulates on the air filter.

IMPORTANT ***Before cleaning your air conditioner, check if you have turned off the circuit breaker.***

1 Open the upper front grille by pulling the lower right and left tabs of the grille.



2 Pull air filters out of each tab of the grille.

3 Remove all dust on the air filters with a vacuum cleaner or brush.



4 When you finish, insert air filters by fixing them to each tab of the grille.

5 To close the front grille, fix it to hooks and push down the lower right and left tabs of the grille.



6 Clean the front grille with a damp cloth and mild detergent (do NOT use benzene, solvents or other chemicals).

Note ***If you have not used the air conditioner for a long time, select the Fan mode for 3 to 4 hours to dry the inside of the air conditioner.***

Cleaning Deodorizing and Bio Filter (Option)



There are Deodorizing and Bio filters inside your air conditioner. They remove odors and dust in your room. You should clean the filters every 3 months.

1 Open the upper front grille by pulling the lower right and left tabs of the grille.

2 Pull out the deodorizing and Bio filter.

3 Wash the filters with clean water, then dry them in the shade.

4 Insert the filters in their place.

Note You can change the position of filters with each other.

5 Close the front grille.

Periodical Checks

Type	Description	Monthly	Every 4 months	Once a year
Indoor unit	Clean the air filter	● (1)		
	Clean the condensate drain pan (2)			●
	Thoroughly clean the heat exchanger (2)			●
	Clean the condensate drain pipe (2)		●	
	Replace the remote control batteries			●
Outdoor unit	Clean the heat exchanger on the outside of the unit (2)		●	
	Clean the heat exchanger on the inside of the unit (2)			●
	Clean the electric components with jets of air (2)			●
	Verify that all the electric components are firmly tightened (2)			●
	Clean the fan (2)			●
	Verify that all the fan assembly is firmly tightened (2)			●
	Clean the condensate drain pan (2)			●

❉ *The checks and maintenance operations described are essential to guarantee the efficiency of the air conditioner. The frequency of these operations varies according to the characteristics of the area, the amount of dust, etc.*

(1) The described operations should be performed more frequently if the area of installation is very dusty.
(2) These operations must always be performed by qualified personnel. For more detailed information, see the Installation Manual.

Protections enabled by the Unit control system

Type of protection	Description	Operation	When it enables
Protection against cold air	The internal fan is off	Heating on heat pump	During operation
Defrost cycle	The internal fan is off	Heating on heat pump	During operation
Anti-frost protection of internal battery	The compressor is off	Cooling During operation	
Delayed start of compressor	The start of the compressor is delayed.	Cooling or heating on heat pump	At start-up or during the selection of the operating mode

CAUTION

If the air conditioner is operating in heat pump mode, it performs several defrost cycles in order to remove the frost that may have deposited on the outdoor unit (at low temperatures).
In this case, the internal fan is switched off automatically and restarted only after the defrost cycle is completed.

Memo

SAMSUNG

ELECTRONICS

Contact SAMSUNG WORLD WIDE

If you have any comments or questions regarding a Samsung product, contact the SAMSUNG customer care center.

Country	Customer Care Center ☎	Web Site
CANADA	1-800-SAMSUNG(726-7864)	www.samsung.com/ca
MEXICO	01-800-SAMSUNG(726-7864)	www.samsung.com
U.S.A	1-800-SAMSUNG(726-7864)	www.samsung.com
ARGENTINE	0800-333-3733	www.samsung.com/ar
BRAZIL	0800-124-4214004-0000	www.samsung.com
CHILE	800-SAMSUNG(726-7864)	www.samsung.com/cl
Nicaragua	00-1800-5077267	
Honduras	800-7919267	
COSTA RICA	0-800-507-7267	www.samsung.com/latin
ECUADOR	1-800-10-7267	www.samsung.com/latin
EL SALVADOR	800-6225	www.samsung.com/latin
GUATEMALA	1-800-299-0013	www.samsung.com/latin
JAMAICA	1-800-234-7267	www.samsung.com/latin
PANAMA	800-7267	www.samsung.com/latin
PUERTO RICO	1-800-682-3180	www.samsung.com/latin
REP. DOMINICA	1-800-751-2676	www.samsung.com/latin
TRINIDAD & TOBAGO	1-800-SAMSUNG(726-7864)	www.samsung.com/latin
VENEZUELA	0-800-100-5303	www.samsung.com/latin
COLOMBIA	01-8000112112	www.samsung.com.co
Turkey	444 77 11	www.samsung.com
SOUTH AFRICA	0860-SAMSUNG(726-7864)	www.samsung.com
U.A.E	800-SAMSUNG (726-7864) 8000-4726	www.samsung.com

Ⓒ Samsung Electronics Co., Ltd. All Rights Reserved.

SAMSUNG

USER'S MANUAL

AQV36J✳✳

ENGLISH

ESPAÑOL

FRANÇAIS

Split - type Air Conditioner

(Cooling and Heating)

INVERTER



ⒺⓈⒻ DB98-29386A(1)